










# **AFX Series Software**



## **Take Control of your AFX Series Power Source**

### **Programming - PPSC Studio**



Control all output settings from a single screen.

#### Metering

© 120.4 -			
Function	Phase A	Phase B	Phase C
V(AC)L-N	114,9997	114.9984	115.0009
V(AC)L-L	199.1842	199.1852	199.1864
V(DC)	-0.0004	0.0016	-0.0007
V(ACDC)	114.9997	114.9984	115.0009
Irms	24.1312	24.0639	24.0424
lpeak	34.3212	34.1942	34.1677
Icrest	1.4142	1.4143	1.4143
KW	2775.0010	2767,0012	2764.0007
KVA	2775.0151	2767.2074	2764.0049
PF	1.0000	0.9997	1.0000
Frequency	400.0000	400.0000	400.0000
Degrees	0	120.0	240.0


Extensive AC and DC measurements on all output phases.

### **Source Control - PPSC Control**



Configure Output Modes, User Limits and Self Calibration mode from the PPSC Control screen.

#### **Interface Selections**




Choose from a range of available interface options like LXI (LAN), USB, Serial or GPIB.


# **PPSC Test Manager Option**



Develop elaborate AC or DC test sequences using the PPSC Test Manager option or select from our extensive library of compliance test sequences for Avionics, Military or Commerical products.



Test sequence steps provide detailed amplitude and timing control over all outputs in single, split, or three phase mode of operation as needed.



Unique graphical transient pre-view mode allows detailed preview and checking of transient timing before execution.



17692 Fitch, Irvine, CA 92614 USA
Phone: +1 949.251.1800
Fax: +1 949.756.0756
Toll Free: 800.854.2433
E-mail: sales@pacificpower.com
www.pacificpower.com

**AVAILABILITY:** PPSC Manager software is available to registered users on Pacific Power Source's Website (pacificpower. com). Microsoft Windows 10<sup>™</sup> OS recommended.